

30" Dual Fuel Range Top Parts List

<u>Ref #</u>	<u>Part #</u>	<u>Description</u>
1	806648	Grate, Burner W/Rubber Pad
2	805233	Filler Grate Assembly, DF30
3	804514	Burner Cap Assy, Lg
4	804512	Burner Cap Assy, Sml
5	804877	Burner Head, Sml
6	804875	Burner Head, Lg
7	802146	Venturi, Lg
8	800488	Venturi, Small
9	805299	Igniter, 9.2K
	802449	Igniter, 15K
10	802399	Inner Distribution Ring, Lg
11	804358	Inner Distribution Ring, Sml
12	720824	Spring
13	802499	Clip, Electrode
14	804874	O-Ring Seal Kit - 1Lg Burner
15	804876	O-Ring Seal Kit - Sml Burner
16	801274	Lead Wire, 30"
17	804331	Burner Pan, DF30
18	802398	Outer Distribution Ring, Lg
	802276	Outer Distribution Ring, Lg Lp
19	804122	Orifice, Main, Nat, Lg
	804123	Orifice, Main, Lp, Lg
20	802404	Jet Holder, Lg-Natural
	802405	Jet Holder, Lg-Lp
21	800470	Outer Distribution Ring, Sml
	802679	Outer Dist. Ring, Small, Lp
22	801325	Orifice, Main, Nat, Sml
	801319	Orifice, Main, Lp, Sml
23	800486	Jet Holder, Sml
	802677	Jet Holder, Small, Lp
24	804138	Deflector Shield, Burner
25	801232	Spark Module 0+1
26	804633	Regulator Box Top
27	802032	Burner Support
28	804373	S-Grate Package, Df
	805686	S-Grate Filler, DF30

Not Shown

802325	Wire Harness, Main
804124	Orifice, Simmer, Nat, Lg
804125	Orifice, Simmer, Lp, Lg
802947	Orifice, Simmer, Nat, Sml
802948	Orifice, Simmer, Lp, Sml
804372	Wok Grate w/Feet