

Parts List with Exploded View **OUTDOOR BBQ-2 GRILLS** **WOLF®**

Chassis Parts List

<u>Ref #</u>	<u>Part #</u>	<u>Description</u>	<u>Ref #</u>	<u>Part #</u>	<u>Description</u>
1	786232	Hood, Top 24"	39	720511	Burner, Pilot LP
	786233	Hood, Top 36"		720513	Burner, Pilot Nat. Gas
	786234	Hood, Top 48"	40	801050	Screw, 8-32x1/2
2	730549	Screw, Shoulder	41	720638	Electrode, Spark 48"
3	722573	Bushing, Flanged	42	786227	Hood, Rear Top 24"
4	722778	Ring, Retainer		786228	Hood, Rear Top 36"
5	801054	Washer, 5/16 Flat		786229	Hood, Rear Top 48"
6	801055	Nut, 5/16-18 Hex	43	766738	Panel, Rear Open Brnr
7	719987	Plug, Button	44	786160	Panel, 24" Rear Grill
8	730101	Screw, 1/4-20 x 1		786161	Panel, 36" Rear Grill
9	730320	Washer, 1/4 Lock		786162	Panel, 48" Rear Grill
10	730334	Washer, 9/32 x 1	45	786226	Hood, Rear RH
11	722639	Washer, Hood Handle	46	720536	Spacer, Hood Guide
12	722625	Handle, Hood 24"	47	730031	Screw, #8 8/32xTr
	722626	Handle, Hood 36"	48	786279	Support, Rod RH
	722627	Handle, Hood 48"	49	766723	Frame, Open Burner
13	801099	Screw, #10-16 x 1/2		766737	Spacer, Open Burner
14	801123	Grate, Filler		801317	Screw, 1/4-20x1/2"
15	722579	Grate, Broiler Large		730320	Washer, 1/4 Lock
	722580	Grate, Broiler Small	50	801211	Screw, 8-32 Acorn S/S
16	800492	Burner, BBQ Tube	51	786225	Hood, Rear LH
17	806103	Radiant	52	766606	Chassis, Grill 24"
18	766733	Frame, Step-up		766607	Chassis, Grill 36"
19	714690	Grate, Side Burner		766608	Chassis, Grill 48"
20	719332	Handle 4"x13/16"	53	730553	Nut, 8-32 Acorn S/S
21	766739	Cover, Open Burner	54	714521	Strap, Spark Ground
22	801364	Screw, 10-24x1/2"	55	806097	Bracket, Sparker
23	720552	Counterbalance, Assy.	56	806123	Burner Box Assy., BBQ24
24	720544	Rod, Rotisserie 24"		806113	Burner Box Assy., BBQ36
	720545	Rod, Rotisserie 36"		806104	Burner Box Assy., BBQ48
	720546	Rod, Rotisserie 48"	57	801491	Grease Can, 24"
25	720548	Fork, Rotisserie Assy.		801492	Grease Can, 36"
26	730247	Screw, 1/4-20x3/4 Th		801493	Grease Can, 48"
27	720617	Handle, Rotisserie	58	766729	Drip Pan, Open Burner
28	766692	Shield, Pilot IR Burner	59	801670	Drip Pan, 24"
29	786211	Panel, Splash 24"		801671	Drip Pan, 36"
	786212	Panel, Splash 36"		801672	Drip Pan, 48"
	786213	Panel, Splash 48"	60	730031	Screw, #8 8/32xTr
30	800800	Orifice, #55 Nat Small	61	809802	Motor Support Assy
	800048	Orifice, #50 Nat Large	62	713777	Bracket, Bar LH
	800803	Orifice, #64 LP Large		713778	Bracket, Bar RH
	800804	Orifice, #65 LP Small	63	722773	Bumper, Hood
31	800258	Elbow, 3/8" x 3/8" MNPT7/16" - 27	64	809798	Motor, Rotisserie (See S/N Break)
32	715554	Burner, Infrared Small		810203	Rotisserie Package-24 (See S/N Break)
	715555	Burner, Infrared Large		810204	Rotisserie Package-36 (See S/N Break)
33	786180	Cover, IR Burner 24"		810205	Rotisserie Package-48 (See S/N Break)
	786181	Cover, IR Burner 36"	65	722224	Tubing, Flex 3/8x30
	786182	Cover, IR Burner 48"		722225	Tubing, Flex 3/8x36
34	722565	Pull, IR Cover		722462	Tubing, Flex 3/8x42
35	730031	Screw, #8 8/32xTr	66	807474	Screw, 10-24x1-1/2
36	800914	Nut, 3/16 Compression	67	811366	Valve, Safety w/Fitting
37	720889	Ferrule, 3/16	68	766624	Bracket, Safety Valve
38	801183	Orifice, Pilot Burner,Nat.	69	801213	Screw, 1/4-20x1.5
	801184	Orifice, Pilot Burner,LP	70	720556	Bar, Belly 1"x24-1/2
			71	722223	Tubing, Flex 3/8x24