




CABINET



Item #	Part #	Description
1	A28861023	Cabinet/Shell
2	02386701	Support, Hinge Mount
3	03381401	Screw, #8-32X3/8 Fill Hd (8)
4	13082801	Gasket, Decor Trim
5	13093501	Seal, Bin (EPS Sheet)
6	A37814001	Face Plate, Upper Cabinet
7	03381301	Screw, #10-24X5/8 Hd (4)
8	02385701	Trim Ring, Bin
9	13093601	Gasket, Door
10	A37886021	Door
11	02386601	Hinge, Top RH / Bottom LH
12	03381801	Screw, #10-24X1/2 (10)

Item #	Part #	Description
13	02385901	Cover, Upper Hinge/Door, RH
	02385902	Cover, Upper Hinge/Door, LH
14	A37854001	Bracket, Panel Mount Top
15	03163803	Screw, #8-32X3/8 (2)
16	A37822001	Bracket, Panel Mount
17	02386602	Hinge, Top LH / Bottom RH
18	A37855001	Bracket, Panel Mount Bottom
19	02385801	Knob, Bin Thermostat
20	A37819021	Control Panel Assy
21	03381701	Dual Lock Fastener (2)
22	03141807	Screw, #10-24X1/2 Flat Hd(4)
23	A37815001	Face Plate, Lower Cabinet
24	03381601	Screw, #8X1/2 Black (2)
25	02224302	Kickplate
26	03140407	Screw, #6 (3)
27	A37858001	Panel, Inner Control Access
28	03141908	Screw, A B Flat Hd (2)
	02270101	Spacer (1)
29	03140408	Screw, Thread Forming (9)
30	A29102001	Rear Panel
31	03143100	Screw, #10 (6)
32	03160801	Leveler Leg (4)
33	12163807	Power Cord
34	A26787001	Insulation (in bag)
35	08066401	Scoop
36	02398801	Filler, Kickplate